

種別	メーカー	機種名	数量	備考
ミキサー卓				
	ROLAND	M-200i	1	16MIC INPUT / 8 LINE INPUT / 12 ASSINABLE OUTPUT (8AUX BUS / 4MATRIX BUS / LR MASTER)
	YAMAHA	MX12/4	1	移動可 8 MONO INPUT / 2 STEREO INPUT / 2 AUX OUT / 4 GROUP OUT / 1STEREO MASTER)
グラフィックEQ				
	YAMAHA	Q1031	4	移動不可 Single Chanel 31 Band (1/3 octave)
再生機器				
	TASCAM	MD350	1	MDデッキ
	DENON	DN-700C	2	CDデッキ USBメディアからデータ再生可能 (WAV AIFF AAC MP3)
ダイナミックマイク				
	SHURE	SM57LCE	5	
	SHURE	SM58LCE	5	
	AUDIX	OM3	2	
	audio-technica	ATM-25	1	
	National	WM-333 (スイッチ付き)	2	
コンデンサーマイク				
	AKG	C391	2	
ワイヤレスマイク				
	SHURE	UT4/SM58 (ハンド)	2	Handheld Transmitter (周波数固定)
	SENNHEISER	EW112-J (ラベル)	1	Bodypack Transmitter with Lavalier Microphone
マイクスタンド				
	K&M	210	8	ロングブーム・シルバー
	K&M	259	5	ショートブーム・シルバー
	National	卓上スタンド	3	
メインスピーカ				
	cerwin vega	PS15SII (ハイボックス)	4	600W (連続プログラム) 60°×60°
	cerwin vega	PS215B (サブウーハー)	4	800W (連続プログラム)
メインスピーカ				
	BOSE	802II	2	240W(RMS) キャットウォーク下に常設固定
モニタースピーカ				
	E/V	SX200	2	
小型スピーカ				
	RAMSA	WS-A10	4	
パワーアンプ				
	QSC	GX-5	1	メイン(HI)用 300w×2/8Ω
	PHONIC	XP3000	1	メイン(LO)用 600W×2/8Ω
	Roland	SRA540	4	モニター用 (フロア) 270w×2/8Ω
	RAMSA	WP9220	1	常設BOSE用 220w×2/8Ω
マルチ回線				
		音響ブースパッチ盤-ステージ上手	1	16ch
		音響ブースパッチ盤-客席	1	12ch
		音響ブースパッチ盤-バックヤード	1	4ch

Mixing Desk		
1	ROLAND M-200I(fixed installation)	16MIC INPUT / 8 LINE INPUT / 12 ASSINABLE OUTPUT (8AUX BUS / 4MATRIX BUS / LR MASTER)
1	YAMAHA MX12/4	移動可 8 MONO INPUT / 2 STEREO INPUT / 2 AUX OUT / 4 GROUP OUT / 1STEREO MASTER)
Graphic Equalizer		
4	YAMAHA Q1031(fixed installation)	Single Chanel 31 Band (1/3 octave)
Playback		
1	TASCAM MD350 with autostop	Minidisc player(fixed installation)
2	DENON DN-700C	CD player(fixed installation)
Dynamic Microphone		
5	SHURE SM58LCE	
5	SHURE SM57LCE	
2	AUDIX OM3	
1	AUDIO-TECHNICA ATM-25	
2	National WM-333	
Condensor Microphone		
2	AKG C391	
Wireless Microphone		
2	SHURE UT4/SM58	Handheld Transmitter
1	SENNHEISER EW-112-J	Bodypack Transmitter with Lavalier Microphone
Mic Stand		
8	K&M 210 Long Type Boom Arm	
5	K&M 259 Short Type Boom Arm	
3	National Table Stand	
Loud Speaker		
4	Cerwin Vega PS15SII 15" Two-Way Loud Speaker	600 watts continuous program power
4	Cerwin Veta PS215B 15" Subwoofer	800 watts continuous program power
2	Electro-Voice SX200 12" Two-Way	
2	BOSE 802II(fixed installation)	
4	RAMSA WS-A10	
Power Amplifier		
1	QSC GX-5	300w×2/8Ω
1	PHONIC XP3000	600W×2/8Ω
4	Roland SRA540	270w×2/8Ω
1	RAMSA WP9220	220w×2/8Ω
1	Multicore 16ways, fixed installation between patch board operator side and stage left.	

Attention: the theatre has no workshop. All stuff like tools, wood, cloths and other consumer material has to be provided by the company.